Numer kolumny	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38
Parametr	Engine speed	Battery voltage	Throttle position	Engine MAP	Lambda voltage	Intake air temp	Coolant temp	Car speed	Air Fuel Ratio	BRAK DANYCH	Ignition angle	IAC position	Idle target RPM	Injection time	Warmup enrich	Afterstart enrich	Dwell time	Knock value	Knock level	Engine noise	nock ignition reta	TPS acceleration	ir temp correctio	GO fuel correctio	Boost target	Boost PWM	Fuel consumptior	Alcohol content	Fuel temperature	Debug1 16b	Debug2 16b	Injectors DC	aust gas tempera	Trigger error	Lambda target	Lambda	Analog IN	NTC
Współczynnik wartości RAW	1	0,078125	0,098	1	0,078125	1	1	1	0,147	1	0,25	1	1	0,004	0,78	0,78	0,064	0,02	0,02	0,02	0,25	1	1	-128	1	1	0,068	1	1	1	1	1	1	1	0,01	0,01	0,0049	0,6
Przesunięcie wartości RAW	0	0	0	0	0	-40	-40	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	-50	0	0	0	0	0	-40	0	0	0	0	0	0	0	0	0